



Installing Lapped Sidings

For a horizontal application, start with the bottom course and work up with the beveled sides of the channels pointing upward. Allow a 1/8" expansion gap between each piece of siding. Do not nail through overlaps. Use one nail 1" up from the lap. Nails must penetrate solid wood 1-1/2".

